



EQUIPMENT



PARTS



RENTALS



SERVICE



SUPPLIES

SPARE PARTS MANUAL

CONTACT US

☎ 800.6.Bortek

📠 717.737.7591

✉ Orders@BortekIndustries.com

🌐 BortekIndustries.com/CUSTOMERLINK




HAMMERHEAD[®] 900SX



Group 0





N. Pos.	Cod.	Description	Q.ty
1	6020014AQJ	Frame	1
2	AAA0606000	M6 Lock nut	Qr
3	C072420010	D.20x10 Shock absorber	2
4	A140606016	M6x16 Screw	Qr
5	A900506000	Washer	Qr
6	6010014APX	Flap lifting cable	1
7	6110014AGC	Drawer mousse	2
8	6110014AGC	Drawer mousse	1
9	6110014AGF	Mainfold mousse	1
10	E260932000	D.32 Fitting for hose	1
11	E277000000	D.20 Clamp	3
12	6120014AJZ	Hole cover adhesive	Qr
13	C111100000	D.17,4 Cover hole cap	1
14	E260110000	Inverter lever fitting for hose	1







N. Pos.	Cod.	Description	Q.ty
1	C330200000	D.125x37,5 Pivoting wheel+brake	1
2	AAA0606000	M6 Lock nut	Qr
3	A140606016	M6x16 Screw	Qr
4	A900506000	Washer	Qr
5	6020014ADJ	Flap lifting lever	1
6	6020014ACZ	Centering flap lifting plate	1
7	A141006025	M6x25 Screw	Qr
8	A140906020	M6x20 Screw	Qr









N. Pos.	Cod.	Description	Q.ty
1	6020014ALP	Flap lifting plate	1
2	6020014ALT	Flap plate	3
3	6110014ALR	Front flap	1
4	A600106020	M6x20 Screw	Qr
5	6110014ALQ	Drawer rubber strap	1
6	AAA0606000	M6 Lock nut	Qr







N. Pos.	Cod.	Description	Q.ty
1	E271600000	D.22 Stop collar	4
2	6110014AFN	Side rubber strap	1
3	6020014ADG	Side flap plate	1
4	AAA0606000	M6 Lock nut	Qr
5	A311406045	M6x45 Screw	Qr
6	A600106020	Screw	Qr
7	6110014ALS	Rear rubber strap	1
8	6110014ALR	Front flap	1
9	6020014ALT	Flap plate	3
10	6020014ALU	Flap lifting plate	1
11	6110014ANG	Filter gasket	1
12	6110014AMK	Drawer mousse	1




Ed. 06/16 - Rev. 01








N. Pos.	Cod.	Description	Q.ty
1	6110014AGF	Manifold mousse	1
2	E260932000	D.32 Fitting for hose	1
3	A511205006	M5x6 Screw	Qr
4	6110014ANG	Filter gasket	1







N. Pos.	Cod.	Description	Q.ty
1	6020014ADD	Filter shaker support	1
2	6020014ADF	Plate	2
3	6020014AHP	Spacer	4
4	A900506000	Washer	4
5	A141106030	M6x30 Screw	4
6	6170014AKL	Pad	1
7	6010014AKK	Fiter shaker cable	1
8	AA20406000	M6 Nut	Qr
9	AAA0606000	M6 Lock nut	Qr
10	C031200000	M6 Handle	1
11	6260014ANS	Dashboard bushing	1
12	AAR0811000	Stop ring	1






N. Pos.	Cod.	Description	Q.ty
1	4290014AMB	Sack filter assy	1
		Comprised of :	
2	6020014ALZ	Frame	1
3	6020014AMA	D.8 Rod	6
4	6110014ALV	Filter spacer	3
5	6200014ALW	Sack filter	1
	6200014ANP	GORE sack filter (Opt)	1
6	6110014APM	Filter chassis mousse	1





N. Pos.	Cod.	Description	Q.ty
1	6470014ALE	Drawer	1
2	6020014AMF	Drawer handle	1
3	C280700000	D.75 Wheel	2
4	6020014ADM	Drawer coupler	1
5	6020014ADN	Block pin plug	4
6	6020014ADP	Drawer wheel pin	2
7	A310606016	M6x16 Screw	4
8	A890506000	D.6x13 Washer	8
9	A600106035	M6x35 Screw	4
10	A600106016	M6x16 Screw	4





N. Pos.	Cod.	Description	Q.ty
1	6470014AQS	Filters cover	1
2	D929200000	Door lock	1
3	A600104030	M4x30 Screw	3
4	A600106030	M6x30 Screw	5
5	AAA0204000	M4 Lock nut	3
6	A900204000	Washer	3
7	6110014APL	Mousse	1





TABLE 0.7

Ed. 06/16 - Rev. 01




N. Pos.	Cod.	Description	Q.ty
1	6020014ACL	Spacer	2
2	D76B300000	Bearing	4
3	6020014ALL	Bar	1
4	6020014ABJ	Main brush arm	2
5	6020014ACK	Bushing	1
6	A151108030	M8x30 Screw	2
7	6260014ACN	Main knob rod	1
8	6260014ACH	Brush shaft	1
9	AAT2135000	Stop ring	2
10	6060014AAC	Brush hub trasmission	2
11	A901608000	D.8x32 Washer	2
12	A991608000	D.8 Washer	4
13	6020014ACF	Trasmission plate	1
14	6260014ACJ	Idle brush axle	1
15	A150808020	M8x20 Screw	2
16	6020014ACM	Knob rod	2
17	A812206013	Screw	2
18	6040014ABP	D.120 Pulley	1
19	6000005093	M10 Hand-wheel	2
20	AB60300015	5x5x15 Key	1
21	6020014ADG	Side flap plate	1
22	6020014ACG	Cover	1
23	6110014AFN	Side rubber strap	1
24	AAA0606000	M6 Lock nut	4
25	A140306012	M6x12 Screw	1
26	C046200000	Hand-wheel	2
27	A900506000	D.6x18 Washer	1
28	A903210000	Washer	1
29	A900708000	D.8x24 Washer	1
30	A150608016	M8x16 Screw	1
31	A510505016	M5x16 Dowel	1
32	C041100000	M6x16 Wing nut	1
33	AA10710000	M10 Nut	1
34	6240014APN	PPL Brush	1






N. Pos.	Cod.	Description	Q.ty
1	6020014ADB	R.H. Arm	1
2	6190014ARP	R.H.12V Motorgear	1
3	6240014APP	Side PPL brush	1
4	AC61208046	D.8x46 Plug	1
5	AB33200000	Spring	1
6	6010014APW	Brush lifting cable	1
7	C071925020	D.25x20 Shock absorber	1
8	A310806020	M6x20 Screw	4
9	AAA0606000	M6 Lock nut	4
10	AA20406000	M6 Nut	1
11	A890506000	Washer	5
12	A052010150	Screw	1






N. Pos.	Cod.	Description	Q.ty
1	B014212010	Bushing	4
2	6260014ACT	Wheel	1
3	6260014ACS	Pin	1
4	6020014ABL	Traction lever	1
5	AAA0808000	M8 Lock nut	1
6	C045900000	Knob pipe	2
7	D161200000	R.H. Double lever	1
8	D161600000	Traction lever control	1
9	6010014APW	Side brush lifting cable	1
10	6010014APY	Flap lifting cable	1
11	6010014AQA	Traction cable	1
12	6020014AQP	Handle pipe	1



Ed. 06/16 - Rev. 01







TABLE 0.9.2

Ed. 06/16 - Rev. 01





N. Pos.	Cod.	Description	Q.ty
1	6260014ABE	Brush shaft reduction	1
2	6250014AAG	Toothed wheel	1
3	D092500000	Support	2
4	6040014ABR	D.175 Pulley	1
5	6040014ABQ	D.70 Pulley	1
6	6010014AAX	Belt	1
7	6010014AAW	Belt	1
8	A521306010	M6x10 Screw	1
9	A511205006	M5x6 Screw	2
10	AB60600020	5x5x20 Key	3
11	A140606016	M6x16 Screw	2
12	A900506000	D.6x18 Washer	2
13	AAA0606000	M6 Lock nut	4
14	A601106016	M6x16 Screw	4







N. Pos.	Cod.	Description	Q.ty
1	D65JR00000	Gasoline engine	1
2	A140606016	M6x16 Screw	Qr
3	A900506000	D.6x18 Washer	Qr
4	6020014AMV	Muffler terminal	1
5	6020014AJA	Muffler deflector	1
6	D453100000	M14x1,5 Nipple	1
7	D480300000	M.3/8" Cap	1
8	6211630565	Spring	1
9	AAA0808000	M8 Lock nut	Qr
10	A762904013	Screw	4
11	E277000000	D.20 Clamp	2
12	6000034777	Motor oil pipe discharge	1






N. Pos.	Cod.	Description	Q.ty
1	AAA0606000	M6 Lock nut	Qr
2	6020019898	Lower hood fixing angular	1
3	C071925020	D.25x20 Shock absorber	1
4	A890506000	D.6x13 Washer	Qr
5	A140606016	M6x16 Screw	Qr
6	6020014AFV	Support	1
7	6010014AAV	Starter cable	1
8	6020014AFS	Ignition and starter support	1
9	AAA0808000	M8 Lock nut	Qr
10	A130605016	M5x16 Screw	1
11	AAA0505000	M5 Lock nut	1
12	A893008000	D.8x17 Washer	5
13	6211630565	Spring	1
14	D480300000	M.3/8" Cap	1
15	A151308040	M8x40 Screw	4
16	AC80100006	M6 Rivet	1






N. Pos.	Cod.	Description	Q.ty
1	6020014ADS	D65JR00000 Motor plate	1
2	C076630020	D.30x20 Shock absorber	4
3	A890506000	D.6x13 Washer	Qr
4	A310606016	M6x16 Screw	Qr
5	6040014ABG	D.70 Pulley	1
6	D742700000	Fan	1
7	A511205006	M5x6 Dowel	1
8	A893008000	D.8x17 Washer	Qr
9	A110700000	Screw	1
10	D65JR50000	Key	1






N. Pos.	Cod.	Description	Q.ty
1	6110014AHM	Vertical gasket manifold	1
2	6110014AHL	Lower gasket manifold	1
3	6110014AHJ	Upper gasket manifold	1
4	6020014AHH	Tank protection	1
5	6020014AHG	Manifold	1
6	A140606016	M6x16 Screw	2
7	A890506000	D.6x13 Washer	4
8	A311006025	M6x25 Screw	2






N. Pos.	Cod.	Description	Q.ty
1	6020014ACB	Manifold support	1
2	6150014AAA	Manifold	1
3	6020014ADK	Suction closing	1
4	A890506000	D.6x13 Washer	3
5	6110014AGP	Fan mousse	1
6	A900506000	D.6x18 Washer	2
7	AA20406000	M6 Nut	1
8	A311006025	M6x25 Screw	1
9	A140606016	M6x16 Screw	3
10	6020014ADL	Suction lever	1
11	AAA0606000	M6 Lock nut	1
12	AC41604011	Rivet	5
13	A130605016	M5x16 Screw	1
14	AAA0505000	M5 Lock nut	1
15	A520906025	M6x25 Dowel	1






N. Pos.	Cod.	Description	Q.ty
1	D65JR20000	Muffler protection	1
2	D65JR30000	Muffler	1
3	D65JR40000	Carburettor	1
4	D65JR70000	Gasoline cap	1
5	D65JR80000	Gasoline filter	1
6	D65JR10000	Air filter	1
7	D65JR90000	Voltage regulator	1
8	D65JRA0000	Alternator	1
9	D65AJ80000	Plug	1
10	D65JR60000	Coil	1






N. Pos.	Cod.	Description	Q.ty
1	A310606016	M6x16 Screw	6
2	6040014ABG	D.70 Pulley	1
3	D742700000	Fan	1
4	A890506000	D.6x13 Washer	6
5	A511205006	M5x6 Dowel	1
6	A893008000	D.8x17 Washer	5
7	A151008025	M8x25 Screw	1
8	6190014APQ	12V 400W Electric motor	1
9	E47B000000	6190014APQ Carbon brush kit	1
10	6020014ACA	Electrical motor support	1
11	A150608016	M8x16 Screw	4
12	D65JR50000	L=35 Key	1






N. Pos.	Cod.	Description	Q.ty
1	6260014ALH	Axel shaft	1
2	D092500000	Support	2
3	C301300000	R.H. D.250x54 Wheel	1
4	C301200000	L.H. D.250x54 Wheel	1
5	6040014ABM	Pulley	1
6	6020014ACQ	Spacer	1
7	C301310000	R.H. M12x15 Screw	1
8	C301210000	L.H. M12x15 Screw	1
9	D041301212	Belt	1
10	AB60600020	5x5x20 Key	1
11	A511705016	M5x16 Screw	1
12	A140606016	M6x16 Screw	4
13	AAA0606000	M6 Lock nut	4






N. Pos.	Cod.	Description	Q.ty
1	6470014ALG	White hood	1
	6470014APS	Blue hood	1
2	6020014AMH	Hood support	1
3	6020014AMM	Motor grid	1
4	6110014AML	Gasket motor grid	1
5	A600106012	M6x12 Screw	6
6	A762904013	Screw	14
7	A900708000	Washer	2
8	A150808020	M8x20 Screw	2
9	6070014ARQ	Spacer	2






N. Pos.	Cod.	Description	Q.ty
1	6470014ATJ	Hood	1
2	6020014AMH	Hood support	1
3	A600106012	M6x12 Screw	6
4	6070014ARQ	Spacer	2
5	A150808020	M8x20 Screw	2
6	A900708000	Washer	2






N. Pos.	Cod.	Description	Q.ty
1	6470031AAR	R.H. Side panel	1
2	6020014ADQ	Side panel coupler plate	2
3	C046300000	Hand-wheel	1
4	C044400000	M6x35 Hand-wheel	1
5	A600106012	M6x12 Screw	4






N. Pos.	Cod.	Description	Q.ty
1	6470031AAS	L.H. Side panel	1
2	6020014ADQ	Side panel coupler plate	2
3	C046300000	Hand-wheel	1
4	C044400000	M6x35 Hand-wheel	1
5	A600106012	M6x12 Screw	4



Ed. 06/16 - Rev. 01






N. Pos.	Cod.	Description	Q.ty
1	5330014ATQ	Stickers kit	1
2	6120014ANT	Brush pressure sticker	1
3	6120014ASZ	Battery cover sticker	1
4	6120014ATB	Hammerhaed sticker	2
5	6120014ATC	Hammerhead front	1
6	6120014ATP	900SX R.H. Sticker	1
7	6120014ATH	900SX L.H. Sticker	1
8	6120014ATK	Forbidden smoke sticker	1
9	6120014ATL	Gears danger sticker	1
10	6120014ATM	Machine use improper use notice sticker	1
11	6120014ASS	Warning do not get wet sticker	1
12	6120014ASU	Identification machine label	1



DFRE124300



N. Pos.	Cod.	Description	Q.ty
1	6120014ATA	Dashboard label	1
2	E161100000	Starting switch	1
3	E163700000	Starting key	1
4	E410100000	Diode Mod. EH	1






DFRE124400

Ed. 06/16 - Rev. 01









N. Pos.	Cod.	Description	Q.ty
1	6020014ACY	lectric components support	1
2	E020500000	Fuse box	3
3	E022800000	7,5A Fuse	2
4	E025000000	15A Fuse	1
5	E572600000	Condenser	1
6	E572610000	Condenser clamp	1
7	E151800000	Microswitch	2
8	E252400000	Protection cover	1
9	6020014AKJ	Micro protection	1



Ed. 06/16 - Rev. 01



N. Pos.	Cod.	Description	Q.ty
1	E191200000	Clamps set	1
2	E253600000	Red clamp cover	1
3	E253700000	Black clamp cover	1
4	E438000000	12V Remote switch control	1
5	E020500000	Fuse box	3
6	E022700000	3A Fuse	1
7	E022800000	7,5A Fuse	2
8	6020014ACY	Electric components support	1
9	E251800000	Cable cover	4
10	E320100000	Battery connector	3
11	E02C100000	Fuse box	1
12	E02B700000	60A Fuse	1
13	E151800000	Microswitch	2
14	E252400000	Protection cover	1
15	6020014AKJ	Micro protection	1
16	6020014ASW	Fuses bloc protection	1



TAV. **2.1**

Notes






Group 1





N. Pos.	Cod.	Description	Q.ty
1	E445320000	Power cable	1
2	E445300000	O.B. 12V-10A Battery charger	1
3	6020014AFW	Battery charger support	1
4	6020014ACV	Single battery tray	1
5	6010014AFX	Single battery carpet	1
6	A290704016	M4x16 Screw	4
7	E501700000	Level battery indicator	1
	E501800000	Charge battery and battery level indicator	1
8	AAA0204000	M4 Lock nut	Qr
9	A150608016	M8x18 Screw	4



DFRE124600



N. Pos.	Cod.	Description	Q.ty
1	E501700000	Battery level indicator	1
	E501800000	Charge battery and battery level indicator	1
2	E444800000	O.B. 12V-20A Battery charger	1
3	6020014AHW	Battery charger support	1
4	6020014ACW	Double battery tray	1
5	6010014AHV	Double battery carpet	1





DFRE124700



Group 2

Ed. 06/16 - Rev. 01







HAMMERHEAD®



450**RS**



500**RS** GEN II



500**RSX**



500**SS** GEN II



600**SS**



650**RS**



750**RS**



550**RDX**



650**RDX**



700**RSX**



750**RDX**



900**SX**



870**SR**



1100**SRX**

HEADQUARTERS

4713 Gettysburg Road
Mechanicsburg, PA 17055 USA

CONTACT US

☎ 800.6.Bortek

☎ 717.737.7591

✉ Orders@BortekIndustries.com

🌐 BortekIndustries.com/CUSTOMERLINK

SWEEPERLAND.COM

A complete family of
power cleaning machines.